12V Power Assembly Wiring


Features

- Charging port for primary internal battery
- · Bypass switch to isolate the pack electronics from the battery while charging
- · Secondary battery port just flip the bypass switch and then plug in your emergency power


Overview

For this project we will create two identical Y connectors with 12V DC input, 12V DC output and connect them together with a bypass switch.


Photos



Battery-side wiring Y sub-assembly




Load-side wiring Y sub-assembly



Switch wiring sub-assembly




Two-color LED indicator sub-assembly



Charge & External power sub-assemblies

Diagram



(draw.io source)

Guide

Tools

1. Soldering iron and supplies to wire disconnect switch to guick connect wires

Parts


- 1. 2 x 12V DC rechargeable battery pack (6000mAh)
- 2. 2 x 12V DC M plug to 2 pigtail (18g)
- 3. 1 x 12V DC M to M cable, 3ft (18g)
- 4. 7 x F connector (pre-wired red/black, 18g)
- 5. 7 x M connector (pre-wired red/black, 18g)
- 6. 2 x DC barrel jack (pre-wired red/black, 18g)
- 7. 1 x DPDT mini toggle switch or pre-wired SPST toggle switch for no-solder option


- 8. butt connectors (18g), wire nuts or opt for soldered wire connections
- 9. cable and wire management supplies (zip ties, zip tie mounts) as desired
- 10. <u>1 x 12V Y-Cable -- 1F to 2M ends</u> (if needed for split load such as 12V keep-alive and amp -- also included with Talentcell battery pack, so optional)
- 11. <u>0-# x 12V extension cables</u> (0 or more, depending on mounting locations)

Power Sub-Assemblies

Battery Connection Sub-Assembly

BATTERY SIDE







- 1. Label one 12V pigtail (part #2) BATT
- Connect one bare-wire side of a 12V pigtail to a pre-wired FEMALE quick connector (part #4) using your preferred wire connection strategy. Label the two-wire quick connector CHRG.
- 3. Snip the black wire off of one FEMALE quick connector. Label the connector LED B.
- 4. Connect the other bare-wire side of the 12V pigtail to both a new pre-wired FEMALE quick connector AND the single-wire connector created in the previous step. Connect the three red wires to each other and the two black wires to each other. Label the two-wire FEMALE quick connector BATT SW.

Pack Load Sub-Assembly

LOAD SIDE







1. Label one 12V pigtail (part #2) LOAD

- 2. Connect one bare-wire side of the 12V pigtail to a pre-wired FEMALE quick connector (part #4) using your preferred wire connection strategy. Label the two-wire quick connector EXT.
- 3. Snip the black wire off of one FEMALE guick connector. Label the connector LED R.
- 4. Connect the other bare-wire side of the 12V pigtail to both a new pre-wired FEMALE quick connector AND the single-wire connector created in the previous step. Connect the three red wires to each other and the two black wires to each other. Label the two-wire FEMALE quick connector LOAD SW.

Bypass Switch Sub-Assembly

SWITCH






- 1. Label a MALE quick connector BATT
- 2. Label a MALE quick connector LOAD
- 3. Snip the red wire off of one FEMALE quick connector and label it LED
- 4. Solder the red wire from the BATT connector onto the left center terminal of the DPDT switch
- 5. Solder the red wire from the LOAD connector onto the left bottom terminal of the DPDT switch
- 6. Connect the three black wires from BATT, LOAD, and LED quick connectors using your preferred wire connection strategy

LED Indicator Sub-Assembly


INDICATOR





- 1. Snip the black wires off of two MALE quick connectors, labeling the red wire of one LED B and the red wire of the other LED R
- 2. Snip the red wire off of one MALE quick connector. Label the black wire LED C
- 3. Connect the red wire of the LED to the LED R quick connector red wire
- 4. Connect the blue wire of the LED to the LED B quick connector red wire
- 5. Connect the black wire of the LED to the LED C quick connector black wire

Power Input Sub-Assemblies



- 1. Connect the black and red wires from one pre-wired 12V port to the black and red wires on one MALE quick connector. Label it CHRG.
- 2. Connect the black and red wires from one pre-wired 12V port to the black and red wires on one MALE quick connector. Label it EXT.

Mounting Assemblies

- 1. After drilling your mounting holes, you should be able to feed the MALE connectors on the LED sub-assembly and the power input sub-assemblies through their respective mounting holes
- 2. Pass the shaft of your bypass switch through the hole and use the washers, nut, etc. to affix the switch and attached sub-assembly

Connecting Sub-Assemblies

Using your quick connects and matching labels:

- Connect the CHRG MALE quick connector on the power in sub-assembly to the CHRG FEMALE quick connector on the BATT sub-assembly
- Connect the EXT MALE quick connector on the power in sub-assembly to the EXT FEMALE quick connector on the LOAD sub-assembly
- 3. Connect the BATT MALE quick connector on the SWITCH sub-assembly to the BATT SW

FEMALE connector on the BATT sub-assembly

- 4. Connect the LOAD MALE quick connector on the SWITCH sub-assembly to the LOAD SW FEMALE connector on the LOAD sub-assembly
- 5. Connect the LED B FEMALE quick connector on the BATT sub-assembly to the LED B MALE connector on the LED sub-assembly
- 6. Connect the LED R FEMALE quick connector on the LOAD sub-assembly to the LED R MALE connector on the LED sub-assembly
- Connect the LED C FEMALE quick connector on the SWITCH sub-assembly to the LED C MALE connector on the LED assembly